

DRIFTAWAY

The boring but  
*important stuff*

(Safety, Care and Maintenance)

[www.ergopouch.com.au](http://www.ergopouch.com.au)

SKU	EPWN-TAUPE
Barcode	9352240019825
Rated Power	3W
Max Sound Pressure Level	<75db with 25 volume settings <65db when placed 50cm/20" away from head
Built-in Rechargeable Battery	poly-Li 3.7V 500mAh / 1.85Wh
Charging Voltage	DC 5V/0.5A
Light	SMD LED Mounted on PCBA with 3 brightness settings
Sound Tracks	White Noise, Heartbeat, Shushing, Fan, Rain, Ocean, Nature
Dimensions	Unit Weight: 96g / 0.2 lb Unit Diameter: 8cm / 3.2" Unit Height: 3.7cm / 1.5" Strap Length: 7cm / 2.7" Charging Cable Length: 1m / 39"
Strap Material	Food-grade silicone

## **SAFETY**

### **Important Safety Information**

Please read the user manual and below safety information carefully before use. The Drift Away Portable White Noise Machine is only to be used for its intended use as described in the manuals.

### **Safety Warnings**

1. Never operate this unit if it's damaged. If the unit is not working properly, contact our Customer Service team.
2. Do not store the unit where it can fall or be pulled into a tub, sink or other body of water.
3. Do not place in or drop into water or other liquids.
4. Only place the unit on flat, dry, and firm surfaces. Do not place the unit on wet surfaces.
5. Never drop or insert any object into any opening.
6. Do not carry this unit by its power cable or use the cable as a handle.
7. Before cleaning the unit, always unplug it from the electrical outlet to reduce the risk of electric shock.

### **The Drift Away Portable White Noise Machine is not a toy**

Please do not leave the unit unattended, especially if children are present. Close supervision is necessary when the unit is used by or near children, invalids, or disabled persons.

### **Safe Use During Sleep with a Baby**

Never place the unit inside your baby's cot, bassinet or pram and never near your baby's head or ears.

1. Place the unit on a flat, dry surface, at least 2m/6.6ft away from your baby when in use.
2. Make sure the volume is set to a low setting, similar to that of a quiet conversation or a running shower.
3. Ensure to use the unit only as a background sound, never in the foreground.
4. Be mindful of the intrusive nature of high-volume sounds, especially when your baby is trying to sleep.
5. Use the unit to assist settling your baby to sleep. Once baby is asleep, turn off the unit or alternatively turn the volume down to a lower setting.

**Warning**

Do not use the unit at its highest volume any less than 2m/6.6ft away.

**Travelling with the Unit**

When transporting the unit, unplug the cable and ensure the unit is switched off when not in use. We recommend using the supplied packaging box for transportation to protect the unit. The Drift Away Portable White Noise Machine contains a polymer-lithium rechargeable battery with 1.85Wh, which will be accepted by most airlines in both checked luggage or carry on. Please check with your airline before flying. Do not leave the unit in a hot car for a prolonged period.

## **MAINTENANCE AND CARE**

### **Storage**

Store the unit and cable in its box in a cool, dry place when not in use.

### **Cleaning**

Use a soft, dry cloth to clean the unit, strap and cable. Never use liquids or abrasive cleaners on the unit.

### **Battery Maintenance**

We recommend running the battery down completely before charging again. Rechargeable polymer-lithium batteries naturally diminish maximum charging capacity over time. This is expected to happen over several years. To preserve the life of the battery, do not expose to heat sources, and do not charge erratically. Do not attempt to replace the battery.

Modifications are not authorised by the manufacturer and may void user warranty.

### **Disposal and Recycling Information**

When the unit reaches end of life, please dispose responsibly. If you need to return your used device due to a fault under warranty, please contact the retailer where the product was purchased.

### **General Battery Disposal Information**



The wheeled bin mark indicates that this product should not be disposed with other household waste. To prevent possible harm to the environment or human health from uncontrolled waste disposal, and to promote the sustainable reuse of material resources, please recycle the unit responsibly at a collection point designated by local authorities for safe disposal.

## European Battery Disposal Information



According to the European WEEE Directive (2002/96/EC) and Battery Directive (2006/66/EC), all electrical and electronic products and batteries must be collected separately by a local collection system. Do not dispose of these items with your normal household waste. Follow local regulations for safe disposal. The wheeled bin mark indicates that this product should not be disposed with other household waste throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, and to promote the sustainable reuse of material resources, please recycle the unit responsibly.



## **WARRANTY AND CUSTOMER SERVICE**

ergoPouch provide a one-year limited replacement warranty on this product. This covers the unit, strap and cable, and warrants against defects in the materials and workmanship for one year (12 months) from the date of original retail purchase. The warranty does not cover normal wear and tear, damage caused by accident or misuse, or the natural diminishing of the battery life. ergoPouch will replace or refund your unit at our discretion. Modifications to the unit are not authorised by the manufacturer and may void user warranty. This warranty is in addition to rights provided under local consumer laws. Proof of purchase is required to make a warranty claim.

### **Per Australian Consumer Law**

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

### **To Make a Claim**

To make a warranty claim, or contact us about a faulty product, please email [cs@ergopouch.com.au](mailto:cs@ergopouch.com.au).

## COMPLIANCE



The Drift Away Portable White Noise Machine complies with the following regional certifications.

Region	Certification
Europe	CE, WEEE, REACH, RoHS
North America	RoHS
USA	FCC
USA (California)	California Prop65
Canada	IC
Australia/New Zealand	RCM
UK	UKCA